

ALWAYS CHECK THE OIL LEVEL WITH THE LIFTING ARM IN THE LOWEST POSTION

Current models

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
<u>Jacks, manual</u>					
2T-C	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-F	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-LF (2T-LF2)	0,70	CASTROL - AWS 22		10 mm under the refilling hole	
3T-C	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
4T-C	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
5T-C	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
6T-C	1,00	CASTROL - AWS 22		10 mm under the refilling hole	
8T-C	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
10T-C	2,50	CASTROL - AWS 22		10 mm under the refilling hole	
15T-C	2,60	CASTROL - AWS 22		10 mm under the refilling hole	
20T-C	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
1.5T-HC	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-HC	0,70	CASTROL - AWS 22		10 mm under the refilling hole	
3T-HC	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
5T- HC G1	2,50	CASTROL - AWS 22		10 mm under the refilling hole	
8T-HC G2	2,50	CASTROL - AWS 22		10 mm under the refilling hole	
10T-HC	2,50	CASTROL - AWS 22		10 mm under the refilling hole	
CFLJ-5	0,80	CASTROL - AWS 22		10 mm under the refilling hole	
<u>Jacks, air hydraulic</u>					
AV20-C	1,00	CASTROL - AWS 22		Up to the edge of the refilling hole	8 -10 bar
A2510-C	2,50	CASTROL - AWS 22		Up to the edge of the refilling hole	8 -10 bar
A3216-C	1,90	CASTROL - AWS 22		Up to the edge of the refilling hole	8 -10 bar
A4411-C	2,50	CASTROL - AWS 22		Up to the edge of the refilling hole	8 -10 bar
A4422-C	2,50	CASTROL - AWS 22		Up to the edge of the refilling hole	8 -10 bar

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
<u>Foot operated presses</u>					
FP16		CASTROL - AWS 22			
FP20 G2/G5	2,25	CASTROL - AWS 22			
FP25 G2/G5	2,25	CASTROL - AWS 22			
FP40	4,00	CASTROL - AWS 22			
FP50	4,00	CASTROL - AWS 22			
<u>Hand operated presses</u>					
HP20 G2/G5	2,25	CASTROL - AWS 22			
HP25 G2/G5	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
HP40	4,00	CASTROL - AWS 22	CASTROL - AWS 32	110 mm under the refilling hole	
HP50	4,00	CASTROL - AWS 22			
HP60	6,00	CASTROL - AWS 22	CASTROL - AWS 32	80 mm under the refilling hole	
HP70	6,00	CASTROL - AWS 22			
HP100 G3	6,00	CASTROL - AWS 22	CASTROL - AWS 32	50 mm under the refilling hole	
<u>Electro-hydraulic presses</u>					
EP40	10,00	CASTROL - AWS 32			
EP40 D	14,00	CASTROL - AWS 32			
EP60	15,00	CASTROL - AWS 32			
EP60 D	18,00	CASTROL - AWS 32			
EP100 D	27,00	CASTROL - AWS 32			
EP100-2D-320					
<u>Other presses</u>					
AP20	1,50	CASTROL - AWS 10		25 - 70 mm under the refilling hole	6 - 8 bar
CSC	0,00	No oil in machine	No oil in machine	No oil in machine	

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
<u>Bottle jacks</u>					
CBJ 3	0,09	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 5	0,15	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 10	0,24	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 15	0,34	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 20	0,47	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 25	0,49	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 30	0,55	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ 50	0,85	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ-T4	0,15	CASTROL - AWS 22		Up to the edge of the refilling hole	
CBJ-T10	0,65	CASTROL - AWS 22		Up to the edge of the refilling hole	
<u>Cranes</u>					
CC055		CASTROL - AWS 32		10 mm under the refilling hole	
CC10 G4	0,80	CASTROL - AWS 32		Up to the edge of the refilling hole	
CC15P	1,50	CASTROL - AWS 32		Up to the edge of the refilling hole	
<u>Transmission jacks</u>					
TJ300	0,95	CASTROL - AWS 32			
TJ325 / TJ325 G2	0,95	CASTROL - AWS 32		Up to the edge of the refilling hole	
TJ525 / TJ525 G2	0,95	CASTROL - AWS 32		Up to the edge of the refilling hole	
TJ1000 G2	0,95	CASTROL - AWS 32		Up to the edge of the refilling hole	
TJ-T1300 G3	2,80	CASTROL - AWS 32		Up to the edge of the refilling hole	
TJ-T2000		CASTROL - AWS 32		Up to the edge of the refilling hole	
<u>Wheel dollies</u>					
WD Mobile	0,00	No oil in machine	No oil in machine	No oil in machine	
WD 60	0,95	CASTROL - AWS 22		10 mm under the refilling hole	
WD 800	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
WD 1500 G3	0,80	CASTROL - AWS 22		10 mm under the refilling hole	

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
<u>Hydraulic body repair kits</u>					
CRK 4	0,50	CASTROL - AWS 22		Under the refilling hole	
CRK 10	0,50	CASTROL - AWS 22		Under the refilling hole	
<u>Other models</u>					
PT25-C	0,75				

Old models

<u>Jacks, manuel</u>					
1T-2H	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,3T-H	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-1HL; 1,5T-2HL	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-2	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-2S	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-C	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-H	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-HA	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5TH-LJ	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-H-US	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
1,5T-LJ	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-1B	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-1V	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-2HA	0,70	CASTROL - AWS 22		10 mm under the refilling hole	
2T-2HA-B	0,70	CASTROL - AWS 22		10 mm under the refilling hole	
2T-2L	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-2LS	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-2Q	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-4A	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-4B	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-4K	0,50	CASTROL - AWS 22		10 mm under the refilling hole	

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
2T-4KS	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-4Q	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-4Q-TE	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-5H	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
2t-Au	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2TK-5	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-LJ	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2TQ-LJ	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2TQ-LJ-TE	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2T-V; 2T-V-Boogie	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,25T-2L	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,25T-4K	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,5T-1	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,5T-4K	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,5T-4Q	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
2,5T-5H	1,00	CASTROL - AWS 22		10 mm under the refilling hole	
3T-1B	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
3T-5H	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
3T-V	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
4,5T-4	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
4T-4	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
5T-2QA	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
5T-3Q-US-2	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
6T-2H	1,40	CASTROL - AWS 22		10 mm under the refilling hole	
6T-4	1,00	CASTROL - AWS 22		10 mm under the refilling hole	
6T-K	0,90	CASTROL - AWS 22		10 mm under the refilling hole	
6T-HC	1,40	CASTROL - AWS 22		10 mm under the refilling hole	
7,5T-2H	1,40	CASTROL - AWS 22		10 mm under the refilling hole	
7,5T-4	1,00	CASTROL - AWS 22		10 mm under the refilling hole	
8T-1	1,00	CASTROL - AWS 22		10 mm under the refilling hole	
10T-2A	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
10T-4	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
10T-4M	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
10T-4-US-3	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
10T-K	1,00	CASTROL - AWS 22		10 mm under the refilling hole	
12T-2	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
15T-2	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
15T-2M	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
20T-1M	2,25	CASTROL - AWS 22		10 mm under the refilling hole	
ALU-C G1/G2	0,50	CASTROL - AWS 22		10 mm under the refilling hole	
CFLJ-4	0,80	CASTROL - AWS 22		10 mm under the refilling hole	

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
<u>Jacks, air hydraulic</u>					
A2-2; A3-2	0,50	CASTROL - AWS 22		65 mm under the refilling hole	8 - 10 bar
A2510-3; A2510-4	1,90	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
A4020-1	1,90	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
AM5 1,5T-F	0,55	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 2,5T-5H	1,50	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 3T-C	0,55	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 3T-5H	1,50	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 4T-4	1,50	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 5T-3QA	1,50	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 5T-3Q-US-2	1,50	CASTROL - AWS 22		10 mm under the refilling hole	8 - 10 bar
AM5 10T-2-US	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AM5 10T-4	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AM5 15T-2	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AM5 18T-1	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AM5-18T-2L	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AM5 20T-1-US	2,50	CASTROL - AWS 22		30 mm under the refilling hole	8 - 10 bar
AV20-2; A4020-2	1,90	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
AV22-2; AV20-3	1,90	CASTROL - AWS 22		Up to the edge of the refilling hole	8 - 10 bar
<u>Foot operated presses</u>					
FP20-AA/AR	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	6 - 8 bar
<u>Hand operated presses</u>					
HP15	1,50	CASTROL - AWS 22	CASTROL - AWS 32		
HP20-AR	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
HP20-AA/AR	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	6 - 8 bar
HP25	3,00	CASTROL - AWS 22	CASTROL - AWS 32		
HP25-1 (with 15T pump)	1,50	CASTROL - AWS 22	CASTROL - AWS 32		
HP25 Junior	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
HP100 G1	10,00	CASTROL - AWS 22	CASTROL - AWS 32	40 mm under the refilling hole	
HP125	10,00	CASTROL - AWS 22	CASTROL - AWS 32		

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
<u>Electro-hydraulic presses</u>					
EP25-1/ EP25-1D/ EP25-1D-3/ EP25-1D-4	14,00	CASTROL - AWS 32			
EP100-2/ EP100-2D-3/ EP100-2D-4	27,00	CASTROL - AWS 32			
EP125-2/ EP125-2D-3/ EP125-2D-4	27,00	CASTROL - AWS 32			
EP(MP)150-2D-4	30,00	CASTROL - AWS 32			
EP40-1/ EP40-1D/ EP40-1D-3/ EP40-1D-4	14,00	CASTROL - AWS 32			
EP60-1	14,00	CASTROL - AWS 32			
EP60-2/ EP60-2D-3/ EP60-2D-4	27,00	CASTROL - AWS 32			
MDP10-1	14,00	CASTROL - AWS 32			
MPC10-1/ MPC10-1-H/ MPC10-1D/ MPC10-1D-	11,00	CASTROL - AWS 32			
MPC25-1/ MPC25-1D/ MPC25-1D-3	11,00	CASTROL - AWS 32			
MPC40-1/ MPC40-1D/ MPC40-1D-3	11,00	CASTROL - AWS 32			
<u>Other presses</u>					
ABP20	1,50	CASTROL - AWS 10		25 - 70 mm under the refilling hole	6 - 8 bar
ADP10	1,50	CASTROL - AWS 10		25 - 70 mm under the refilling hole	6 - 8 bar
AP15	1,50	CASTROL - AWS 10		25 - 70 mm under the refilling hole	6 - 8 bar
BP15	2,25	CASTROL - AWS 22	CASTROL - AWS 32	70 - 80 mm under the refilling hole	
DP10-B2, DP6-B2	1,25	CASTROL - AWS 22	CASTROL - AWS 32		
<u>Jacking beams</u>					
JB20-3	0,50	CASTROL - AWS 22			
JB26-3	0,50	CASTROL - AWS 22			
JB20A-5	0,50	CASTROL - AWS 22		95 - 100mm - Safety stop i top position.	8 - 10 bar
JB26A-5C	0,50	CASTROL - AWS 22		95 - 100mm - Safety stop i top position.	8 - 10 bar
<u>Cranes</u>					
CC05/ CC05P; CC05-J	0,80	CASTROL - AWS 32		Up to the edge of the refilling hole	
CC10L	0,80	CASTROL - AWS 32		Up to the edge of the refilling hole	

Type	Litre	Type of oil	Alternative	Correct oil level	Air connection
<u>Transmission jacks</u>					
TJ-T750					
TJ1000 G1	0,95	CASTROL - AWS 32		Up to the edge of the refilling hole	
TJ-T1300 G2	2,80	CASTROL - AWS 32		Up to the edge of the refilling hole	
Ugået Typer					
MP 1 trins	14,00	CASTROL - AWS 22			
MP 2 trins	30,00	CASTROL - AWS 22			
TH 450 LH	0,2 ??	CASTROL - AWS 22		Up to the edge of the refilling hole	
650-1	2,00	CASTROL - AWS 22		Up to the edge of the refilling hole	
		Viskositet 22 ved 40 grader			
<u>Wheel Dollies</u>					
WD 1500 G2	0,80	CASTROL - AWS 22		10 mm under the refilling hole	
<u>Other models</u>					
CPT 22	0,75				
CPT 25	0,75				